


Travel Weighted Average PCI vs. Unweighted PCI

What Does “Travel Weighted” Mean?

Example:



Unweighted Pavement Condition Index

$$\frac{45 + 65}{2} = 55$$

Travel Weighted Pavement Condition Index

$$\frac{(45 \times 5000) + (65 \times 20000)}{(5000 + 20000)} = 61$$